

High Build Primers

- Superior adhesion and sanding
- High solids formula
- Excellent hiding properties
- Used to skillfully finesse the shape and surface of any finish



QUICKFIX
TM

Hurry and place your QuickFix order today!

QF-013/QF-033 High Build Primer Gray/Beige

High Build Primer Gray and High Build Primer Beige are used to skillfully finesse the shape and surface of any finish. These primers fill and hide minor imperfections, sand easily, and offer a high solids formula.

COMPARABLE TO: Dupli-color® DPP104, and Upol® UP0791 Gray/UP0783 Beige

Preparation

Use Matrix Wax & Grease Remover QF-373 per label instructions to remove surface contaminants in area of repair. Sand existing coating and perform necessary repair. Re-clean area to be primed with Matrix Wax & Grease Remover.

Application

Shake can well. Apply 2-3 wet coats, allowing 7-10 minutes between coats. Final sand to a smooth finish after 30 minutes using 400 grit or finer sandpaper. Re-clean with Matrix Wax & Grease Remover before applying topcoat. Turn can upside down and spray to clear actuator tip and prevent clogging.

Tech Tip

Flash/Sanding times will vary based on temperature and application.

Ordering Information

Part Number	Description	Size
QF-013	High Build Primer Gray	12 oz.
QF-033	High Build Primer Beige	12 oz.

