

# MS-78 Euro Urethane Clearcoat



#### **GENERAL INFORMATION**

MS-78 Euro Clearcoat is a medium solids European Style 2:1 mix clearcoat for spot, panel, and overall refinishing. This clearcoat is an economical choice and is extremely versatile.



## 1. COMPONENTS

MS-78
 MH-78F
 MH-78N
 MH-78N
 MH-78S
 Euro Clearcoat Hardener - Normal
 MH-78S
 Euro Clearcoat Hardener - Slow



## 2. MIXING RATIO (2:1)

 Mix two (2) parts MS-78 Euro Urethane Clearcoat with one (1) part MH-78 Series urethane Hardeners.



## 3. POT LIFE @ 77°F (25°C)

Sprayable 30-60 minutes.

**NOTE:** Pot life will shorten as temperatures increase. Matrix Edge  $^{\text{TM}}$  System products are not recommended for use when panel temperature is below  $60^{\circ}\text{F}$ .



#### 4. CLEAN UP

· Clean equipment immediately after use (check local regulations)




#### 5. ADDITIVES

- <u>Accelerator:</u> 1/2 oz per sprayable quart. MX-081 or MX-084 accelerator may be helpful to assure proper curing in colder weather when air dry is the only option.
- <u>Retarder:</u> 10-15% per sprayable quart. Retarder MR-899 will retard, or slow the initial dry allowing slightly more time for overspray to melt in to the surface when spraying in high temperatures, high humidity, or large jobs
- <u>Fisheye Eliminator</u>: 1/2 oz per sprayable quart. MX-01 is generally discouraged, however, when used as recommended, it may help minimize the surface reaction to contamination. The use of this additive is not a substitute for proper cleaning and preparation.
- Flex Additive: 10% of MX-841 to ready to spray MS-78.



#### 6. SURFACE PREPARATION

FOR APPLICATION OVER RECOMMENDED BASECOAT SYSTEM ONLY





## **OEM BLEND AREAS**

Option 1:

- Clean blend area with appropriate Matrix Edge surface cleaner based on local regulatory compliance.
- · Scuff blend area with gray scuff pad and sanding paste
- Sanding paste must be thoroughly washed away
- Reclean blend area with Matrix Edge surface cleaner prior to topcoating

#### Option 2:

- Clean blend area with appropriate Matrix Edge surface cleaner based on local regulatory compliance
- Sand blend areas with P800 P1000 grit paper, for hard to reach areas scuff with gray scuff pad
- Reclean blend area with Matrix Edge surface cleaner prior to topcoating NOTE: Option 1 and 2 the OEM Blend area must be scuffed or sanded completely dull

## 7. TOPCOATS

N/A



#### 8. TECH NOTES

• N/A



#### 9. SUBSTRATES

- · All Matrix Edge Refinish Basecoats
- Existing OEM Finishes



## 10. APPLICATION

- Apply two (2) to three (3) single wet coats.
- Where clearcoating can't be continued to edge of panel the clearcoat edge can be "melted" with MX-840 EZ Blend Edge Blender



## 11. FLASH / DRY TIMES

AIR DRY @ 77°F (25°C)

	Flash (after 1st coat)	5-10 minutes		
	Flash (after 2nd coat)	10-15 minutes		
	Out-of-Booth	30-45 minutes depending on temp		
	Deliver/Polishing/Recoating	8-12 hours		

#### Force Drying @ 140°F (60°C)

Purge Time	10 minutes			
Bake Time	40 minutes			
Deliver/Polishing/Recoating	After 1 hour cool down			

**NOTE:** Dry times may vary due to temperature, humidity, film thickness and airflow. If extreme color sanding and buffing is needed allow overnight dry time.



## 12. SPRAY GUN SET UP

HVLP/LVLP - Fluid Tip Size	1.3 mm - 1.4 mm
----------------------------	-----------------

#### **AIR PRESSURES**

 Refer to spray gun manufacturer's recommendations for regulatory compliance



## 13. PHYSICAL DATA SEE PAGE 2

If used as instructed, this product is designed to comply with the US National Volatile Organic Compound (VOC) Emission Standard for Automobile Refinish Coatings. Confirm compliance with state and local air quality rules before use. The data on this sheet represent typical values. Since application variables are a major factor in product performance, this information should serve only as a general guide. Valspar assumes no obligation or liability for use of this information. UNLESS VALSPAR AGREES OTHERWISE IN WRITING, VALSPAR MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND DISCLAIMS ALLIMPLIED WARRANTIES INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR APARTICULAR USE OR FREEDOM FROM PATENT INFRINGEMENT. VALSPAR WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Your only remedy for any defect in this product is the replacement of the defective product, or a refund of its purchase price, at our option.



## MS-78 Euro Urethane Clearcoat



## 13. PHYSICAL DATA

RTS REGULATORY DATA	2:1	
<u>WITHOUT</u> ADDITIVES	LBS./GAL.	g/L
Actual VOC	3.40	408
Regulatory VOC (less water and exempt solvents)	4.43	531
Density	7.95	953
	WT.%	VOL.%
Total Solids Content	38.0	31
Total Volatile Content	62.0	69
Water	0	0
Exempt Compound Content	19.2	23
Coating Category	Clea	rcoat

WORST CASE RTS REGULATORY DATA <u>WITH</u> ADDITIVES	2:1:5%:1.5%:10% (MS-78:MH-78S:MR-899:MX-01:MX-841)	
	LBS./GAL.	g/L
Actual VOC	3.45	414
Regulatory VOC (less water and exempt solvents)	4.47	536
Density	7.95	953
	WT.%	VOL.%
Total Solids Content	37.7	31
Total Volatile Content	62.3	69
Water	0	0
Exempt Compound Content	18.9	23
Coating Category	Cle	arcoat

**NOTE:** US Regulations allow for the use of exempt compounds for VOC calculations.

#### NOTES

- Valspar does not recommend nor warranty the blending of clear coats. Over reduction or solvent blending of the clear coat will become visible over time due to UV exposure on the blended edge.
   The edge may also fade or peel over time due to the minimal film thickness of the blended edge.
- Valspar recommends applying clear coat to the entire panel. Many
  of today's late model cars do not have a distinct edge or a break line
  on the quarter panel, in these cases Valspar recommends applying
  the clear coat to the roof and the opposite quarter panel.
- This procedure will assure a professional repair, that returns the vehicle back to pre accident condition